

# OIL INSTRUCTIONS!

**ATTENTION!** Only HD-Oil

during break-in period : SAE 10 W

after 600 miles (1000 km) : SAE 20

or : SAE 20 W

temperatures below +14° F (-10°C): SAE 10W

**OIL PAN CAPACITY:** US qts. Imp. pts.

with oil filter 3.5 5.9

without oil filter or replacement 3.2 5.3

Replace oil filter according to  
»Owner's Manual«

**GEAR BOX CAPACITY:** US qts. Imp. pts.

SAE 80 { 3 - speed 1.1 1.8  
4 - speed 1.4 2.3

**REAR AXLE CAPACITY:** US qts. Imp. pts.

M - 2 C 28 - BS 1.2 1.9

**FUEL TANK CAPACITY:** US qts. Imp. pts.

max. 11.9 9.9

**TIRE PRESSURES:** see »Owner's Manual«